

# Funtronix SNT-440 Score Board Instructions

Detailed Manual at: [https://funtronixonline.com/manuals/SNT-X40\(P\)\\_owners\\_manual.pdf](https://funtronixonline.com/manuals/SNT-X40(P)_owners_manual.pdf)

**Never press "Next Period" when clock is stopped unless period or game is over!!!**

**(Clock will reset to default period time and period number will advance!!!)**

## Set Up Scoreboard

1. Pull down on support arm to extend
2. Connect remote control to scoreboard
3. Connect power cord to scoreboard and Power Station, set Power Station inverter switch to ON
4. Set on Scoreboard switch to ON

## Basic operation

1. Set period length using **STO/LTO** buttons (refer to GELL rules by division)
2. Press **START/STOP** to start or pause clock at whistles according to age division rules
3. Press Home or visitor **+1** to add scores
4. After period expires (horn sounds) press **NEXT PERIOD** to advance period number
5. Additional Notes:
  - Penalties – use handheld timers
  - Suddenly blank/Flashing dot – board times out after 10 minutes of clock stop, press any key to wake

## Advanced Operation

1. Time Outs – 1) Stop game clock with **START/STOP**. 2) Hold **STO** or **LTO** 3 seconds to initiate short (<55s) or long time out, adjust time out length with **STO/LTO**, 3) press Start/Stop to begin countdown. To resume game before timeout expires: 1) press **START/STOP** to stop countdown, 2) press **MODE** to return to game clock, 3) press start to resume game clock on whistle.
2. Halftimes – 1) when period ends (horn sounds) hold **NEXT PERIOD** to display halftime clock, 2) Adjust and start clock as described for timeouts. To resume game before break expires: 1) press **START/STOP** to stop countdown, 2) press **NEXT PERIOD** to reset period time and advance period count, 3) press start to initiate game clock on whistle.
3. Overtime – Press **NEXT PERIOD** until Period shows "O". Adjust and start clock as with Timeouts and halftimes.

## Score board Functions

### Period Length Buttons (+STO/-LTO) –

- Before game - Adjusts default period lengths in whole minutes
- In game, when clock stopped - adjusts clock time by 30 seconds for time corrections
- At halftime or timeouts – adjusts time in whole minutes

### Modify Clock Buttons (+SAVE/-LOAD) –

- Before game - Adjusts default period lengths in seconds
- In game, when clock stopped - adjusts clock time by 1 second for time corrections
- At halftime or timeouts – adjusts clock time in seconds

**BRIGHTNESS (Guest +1)** – Long hold to cycle through 3 levels of brightness

**HORN MODE (Home +1)** – Long hold to cycle through three horn modes. Suggest Mode #1 (only at clock expiration, confirmed by a short single horn when configuring)

**MODE/RESET** – Long hold 3 seconds to completely reset clock and score, will flash "PL1" for 3 seconds.